

BLACK Brant II

- 1 to 10.45 scale model of the sounding rocket main factured by BRISTO AEROSPACE LIMITE of Winnipeg.
 - Perfect for getting starte in scale modeling.
- Parachute Recovery.
 Includes two-color deca for lettering, insignia, an
 - modèle à l'échelle 1 è 10.45 de la fusée à son dage fabriquée pa BRISTOL ÆEROSPACE
 - modèle parfait pour celui qui veut faire ses débuts avec ce passe-temps.
 - recouvrement a parachute.
 Dessins ornamentaux à deux couleurs pour le lettrage, l'insigne, et le détait des vis v sont.

SPÉCIFICATION:


Length Longeur	inche pouce
	inche

RECOMMENDED ENGINE

%A6-2	
A5-4	B6-4

Catalog No. SK-3

Catalogue No. SK-3



A. Cut a slot !" from one end. B. Insert one end of the engine retainer in the

1.

- C. Spread glue around the outside of that end, and slide one of the centering rings on so that it is
 - flush with the engine tube.
- D. Cut a 3/16" slot in the other centering ring.
- E. Spread glue around the other end of the tube and slide the centering ring over it.
- F. Wrap a piece of tape around the middle of the tube so as to go over and secure the engine re-
- tainer. G. Cut the nozzle shroud from the pattern sheet and
- place slits at the dotted lines. Cut out a slot from the indicated area. Fold down the slits at the solid line and glue the ends of the shroud together. When dry, place glue on the slits and
- that was cut from the inside is to be positioned over the engine retainer. 2. Spread glue around the inside of the mair body tube up 23/4" and around the rear centering ring. Slide the

engine mount into this end of the tube until the bot-

thoroughly cover all parts of the rocket. Set

aside the model to dry thoroughly. NOTE: It is best to let the model sit over night before

masking if a laquerized enamel is used. If

tom centering ring is flush with the base of the tube.

glue it to the end of the engine mount. The slot

The nozzle shroud is allowed to protrude. PAINTING

The entire rocket should be given an undercoat of glossy white. Another coat may be added to


- regular enamel is used, it should be left several days. 2. Mark off where the stripes go in reference to the fins from the fin marking quide. Extend the lines to either end of the tube. Mask off the stripes... The stripes must be masked off extremely accurately, because the
- lettering decals must fit perfectly inside them. Mask off the fin indicated on the marking quide as "WHITE FIN". Run your thumbnail down all masking tape edges 5.

masking tape edges. Remove the tape by pecling

to be sure they are sealed.

it back against itself.

Paint the entire rocket and nose cone a glossy cherry red. When the paint is dry, run the blade of a modeling knife lightly along all the of them on the balsa. Be careful that the gain direction is as marked. Cut out each of the fins carefully with a modeling knife or razor blade.



3. Cut out the fin pattern and trace three

- use emery board and sandpaper. Sand the fin with extra fine sandpaper. 5. Prepare the body tube by sanding smooth with extra fine sandpaper.
- 6. Apply a coat of sanding sealer to the fins. Both sides should be done at once, then propped on its side to aboid warping. When thoroughly dry, sand lightly with
- fine sandpaper, then apply another coat of sealer. Repeat this, sanding between steps until a smooth glossy surface is attained. Do the same procedure for the nose cone. 7. Cut out the fin marking guide and wrap it around the rear of the body. Mark

model is painted.

STRIPES

Knot shroud lines and shock cord to screw eye.

Stripe widths and locations may be

found from the marking quide.

the tube at each arrow. Connect and


extend the lines. The arrows indicated


as "STRIPE" need not be marked till the

Screw in the screw eye into the conical shoulder. Unscrew it, squirt glue into the hole, then replace the screw eye.

umb i


Glue inside tube at least 1" back.





BLACK BRANT III





ristol ' aerospace